

How to Use the WarmMark

WarmMark is a single-use, ascending time-temperature indicator which alerts users of exposure to unacceptable temperature conditions.

Arming & Use:

(WarmMark Short Run, Long Run, Duo)

- 1. All WarmMark® breach window(s) should be white prior to arming the device.
- 2. Before arming, the WarmMark indicator should be placed in an environment at least 5°C (9°F) below the WarmMark's activation threshold temperature for a minimum of 30 minutes.
- 3. To arm the WarmMark indicator, fold up and pull out the indicator's activation tab until the tab and barrier film have been completely removed.
- 4. If using a WarmMark indicator with an activation threshold temperature below the ambient temperature, immediately place the indicator in the environment to be monitored to avoid activation.
- 5. Remove the adhesive liner from the WarmMark and adhere the indicator to a clean, dry surface.
 - The WarmMark should be located where it will be visible to the receiver of the monitored shipment.
 - b. The WarmMark can be adhered directly to the product being monitored or located inside the packaging.

Interpreting the WarmMark


When the WarmMark is exposed to conditions above the indicator's activation temperature $\pm 1^{\circ}$ C ($\pm 2^{\circ}$ F), a red dye will begin migrating through the run-out window(s).

Run-out times are based on a temperature $2^{\circ}C$ ($4^{\circ}F$) above the indicator threshold. If the temperature is greater than $2^{\circ}C$ ($4^{\circ}F$) above the activation temperature of the device, the run-out will occur faster.

Storage Recommendations

WarmMark indicators should be stored in a cool dark place below the activation temperature of the indicator and between 35-55% relative humidity (RH).

WarmMark Short Run



Threshold Temp	Run-Out Times			
	Brief	Moderate	Prolonged	
-18°C / 0°F	1 hour	3 hours	12 hours	
0°C / 32°F 8°C / 46°F 10°C / 50°F 20°C / 68°F	2 hours	12 hours	48 hours	
5°C / 41°F 25°C / 77°F 30°C / 86°F 237°C / 99°F	30 minutes	2 hours	8 hours	


Threshold Temp	Run-Out Times			
Single Window Indicators				
8°C / 46°F	8 hours			
8°C / 46°F	12 hours			
25°C / 77°F	8 hours			
Customized for COVID-19				
8°C / 46°F	6 hours			
8°C / 46°F	14 days			
25°C / 77°F	6 hours			
25°C / 77°F	48 hours			

www.spotsee.io Rev: 01/2021




How to Use the WarmMark

WarmMark Long Run



Threshold Temp	Run-Out Times					
	Line 1	Line 2	Line 3	Line 4	Line 5	
10°C/50°F	12 hours	30 hours	60 hours	110 hours	168 hours	
31°C/88°F	12 hours	30 hours	60 hours	110 hours	168 hours	

WarmMark Duo



Threshold Temp	Run-Out Times					
	Window 1	Window 2	Window 3	Window 4		
10°C/50°F	3 days	8 days	14 days	-		
34°C/93°F	-	-	-	Within 30 mins		

FOR QUESTIONS OR TROUBLE SHOOTING PLEASE CONTACT TECHNICAL SUPPORT

Email: techsupport@spotsee.io

SpotSee Canada & Americas:

US: +1 800-466-0101 **Outside US:** +1 214-736-4579 **SpotSee Europe, Middle East, Africa:** +31.55.7370 148

SspotSee Asia-Pacific: +86 (21) 6627 6008

www.spotsee.io Rev: 01/2021