

Thermax® Irreversible Temperature Labels

Instructions for Use:

Peel indicator from release paper.

Apply to any clean, grease free surface ensuring that the indicator has adhered to the surface.

A color change from silver white/orange to black indicates that the temperature has been reached.

Storage Conditions:

Products 120°F/50°C or below: Store in a refrigerator inside a sealed bag

Products above 120°F/50°C: Store at room temperature & humidity (i.e. 20°C/68°F & 50% relative humidity)

Hallcrest

www.spotsee.io Rev: 02/2021