

## How to Use the FreezeSafe™

FreezeSafe descending temperature indicators visually alert users when a temperature breach has occurred so that the appropriate actions can be taken.

## **Using the FreezeSafe:**

- 1. The FreezeSafe indicator should appear clear prior to use. The FreezeSafe does not require special arming to be ready to use.
- 2. Remove the FreezeSafe indicator from the roll and adhere the indicator to a clean, dry surface.
  - a. The FreezeSafe should be located as close to the product being monitored as possible and where it will be visible to the receiver of the monitored shipment.
  - b. The FreezeSafe can be adhered directly to the product being monitored or located inside the packaging.

## **Interpreting the FreezeSafe:**

When the FreezeSafe is exposed to temperatures below the stated activation temperature ±1°C\*, the indicator will turn from clear to magenta.

The FreezeSafe will respond according to the chart below:

0°C	Within 30 minutes
2°C	Within 90 minutes



Unactivated



**Transition Zone** 



**Activated** 

## **Storage Recommendations:**

FreezeSafe indicators should be stored out of direct light between 15 and 25°C / 59 and 77°F

www.spotsee.io Rev: AMT 3/2022